

Remote Control Model: RC-5T

Set current time

1. Slide plastic cover downwards to remove plastic cover on the back of remote control
2. Ensure the mode is set to manual by pressing the "M" button to display "MAN"
3. Press and hold down the "Timer" button until hour display flashes
4. Adjust hour display by pressing "Up" or "Down" arrows
5. Press "Right" arrow to toggle over to minute display (use up and down arrows to adjust)
6. Press "Right" arrow to toggle over to day display (use up and down arrows to adjust)
7. Press and hold down the "Timer" button until time display flashes to store in memory

Set automatic timers

1. Ensure the mode is set to auto by pressing the "M" button to display "AUTO"
2. Ensure you select your desired channel number by using left or right arrows
3. Press and hold down the "Timer" button until display defaults to Sunday
4. Single press "Timer" button until you select the desired day
5. Ensure you select the desired blind direction by pressing "M"
6. Adjust hour display by pressing "Up" or "Down" arrows
7. Press "Right" arrow to toggle over to minute display (use up and down arrows to adjust)
8. Press and hold down the "Timer" button until time display flashes to store in memory

Notes:

1. Pressing the "STOP" button will exit setup and WILL NOT save your settings, only by holding down the "TIMER" button until time display flashes will it then store your settings in memory.
2. The timer interval between the auto up blind direction and auto down blind direction must be greater than 32 minutes apart.
Eg. Auto up direction 12:00 and Auto down direction 12:31 will not work on the same day. Generally this is set to 06:30 auto up and 17:30 auto down by default
3. To set the timer to have no action for any particular day adjust the timer hour and minute to "-- : --" by pressing "Up" or "Down" arrows until you reach "-- : --"
4. To switch off timer, toggle to manual mode by pressing "M" to display "MAN"